

## GENERAL

### Throttle Position Sensor

See [Figure 4-40](#). The throttle position sensor (TP sensor) is supplied 5.0 volts from the ECM (5v REF) and sends a signal back to the ECM (TP sensor signal) which varies according to throttle position. The output signal from the TP sensor varies from:

- 0.5-1.5 volts at idle (closed throttle).
- 3.9-4.9 volts at wide open throttle.

A Code 11 will set if the TP sensor signal voltage does not fall within the acceptable range.

#### NOTE

*If the TP sensor is removed and/or replaced, the sensor must be calibrated using a Scanalyzer. See [4.36 THROTTLE POSITION SENSOR](#).*

## DIAGNOSTICS

### Diagnostic Tips

The Scanalyzer reads throttle position in degrees. TP sensor voltage should increase at a steady rate as throttle is moved from idle to wide open throttle. An open or short to ground in R/W or BK/W wires will also result in a Code 11.

Check for the following conditions:

- **Poor connection.** Inspect ECM harness connector for backed out terminals, improper mating, broken locks improperly formed or damaged terminals, poor terminal-to-wire connection and damaged harness.
- **Perform [4.8 WIGGLE TEST](#) to locate intermittents.** If connections and harness check out OK, monitor TP sensor voltage using a Scanalyzer or DVOM while moving related connectors and wiring harness. If the failure is induced, the TP sensor display will change.
- **TP sensor scaling.** Observe the TP sensor voltage display while opening the throttle with engine stopped and ignition switch ON. Display should vary from closed throttle TP sensor voltage (when throttle is closed) to greater than 4.0 volts (when throttle is held wide open). As the throttle is **slowly** moved, the voltage should change gradually without spikes or low voltages being observed.

### Scanalyzer Notes

The Scanalyzer icon appears at those points in the flow chart where the Scanalyzer can be used.




Figure 4-40. TP Sensor Assembly




Figure 4-41. TP Sensor Terminals [88A]

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 11 flow charts.

1. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).
2. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), black socket probe and patch cord.





Figure 4-42. Throttle Position Sensor Circuit


Table 4-14. Wire Harness Connectors in Figure 4-42.

NO.	DESCRIPTION	TYPE	LOCATION
[11]	ECM (gray)	12-place Deutsch	under seat
[14]	Cam position sensor	3-place Deutsch	near starter
[88]	TP sensor	3-place Packard	behind air cleaner backplate



Clear codes and confirm proper operation with no check engine lamp.

Code 11 Test (Part 2 of 2)



## GENERAL

### Oxygen (O2) Sensor

See [Figure 4-43](#). The oxygen (O2) sensor provides a signal to the ECM which indicates whether the engine is running rich or lean.

- A low voltage signal (<0.41 V) indicates the engine is running lean.
- A high voltage signal (>0.56 V) indicates the engine is running rich.

When the air/fuel mixture is ideal, approximately 14 parts air to 1 part fuel, the voltage will be approximately 0.48 V.

## DIAGNOSTICS

### Diagnostic Tips

The Scanalyzer or DVOM displays the signal from the O2 sensor in volts. This voltage will have an average value tending towards lean, rich or ideal value depending on operating temperature of the engine, engine speed and throttle position. An open/short to voltage or short to ground in the V/GY wire will cause the engine to run rich (short to ground) or lean (short to voltage). The engine must be running at part throttle (2500 RPM) for the ECM to detect an O2 sensor failure.

Check for the following conditions:

- **Poor connection.** Inspect the ECM harness connector [11], fuel injector connectors [84, 85] and O2 sensor connector wiring for backed out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection and damaged harness.
- **Dirty/stuck open injectors.** The motorcycle may run lean (dirty/clogged injectors) or rich (stuck open injectors) if there is an injector problem. This could also cause poor fuel economy and performance.
- **Loose O2 sensor.** See [Figure 4-44](#). If the O2 sensor is loose engine performance may be affected. This could also show up as a slow changing O2 sensor voltage on the Scanalyzer.
- **Loose/leaking exhaust.** This can cause a poor ground connection for sensor or allow fresh air into the exhaust system. If fresh air enters exhaust system, the O2 sensor will read a lean condition, causing the system to go rich.

### Diagnostic Notes

1. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).




Figure 4-43. Oxygen Sensor




Figure 4-44. Oxygen Sensor Installed (Typical)





Figure 4-45. Oxygen Sensor Circuit


Table 4-15. Wire Harness Connectors in Figure 4-45.

NO.	DESCRIPTION	TYPE	LOCATION
[11]	ECM (gray)	12-place Deutsch	under seat
[137]	Oxygen sensor	1-place	above starter




Clear codes and confirm proper operation with no check engine lamp.

Code 13 Test (Part 2 of 3)



Clear codes and confirm proper operation with no check engine lamp.





Clear codes and confirm proper operation with no check engine lamp.

## GENERAL

### Engine Temperature Sensor

#### CAUTION

**Do not pull on engine temperature sensor wiring. Excess strain to sensor wiring will cause sensor damage.**

The ECM supplies and monitors a 0-5 volt signal to one side of the engine temperature sensor (ET sensor). The other side of the ET sensor is connected to ground through the engine.

See [Table 4-16](#). The ET sensor is a thermistor device which means that at a specific temperature it will have a specific resistance across its terminals. As this resistance varies, so does the supplied voltage.

- At high temperatures, the resistance of the sensor is very low. This effectively lowers the signal voltage.
- At low temperatures, the resistance is very high, allowing the voltage to rise close to the supplied voltage of 5 volts.

The ECM monitors this voltage to compensate for various operating conditions.

## DIAGNOSTICS

### Diagnostic Tips

The Scanalyzer displays engine temperature in degrees. Once the engine is started, the temperature should rise steadily.

An intermittent may be caused by poor connection, rubbed through wire insulation or a wire broken inside the insulation.

Check the following conditions:

- **Poor connection.** Inspect ECM harness connector [11] for backed out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection and damaged harness.
- **Shifted sensor.** The temperature-to-resistance values table may be used to test the ET sensor at various temperature levels in order to evaluate the possibility of a shifted (out-of-calibration) sensor which may result in driveability problems.

## Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 14 flow charts.

1. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).
2. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), gray pin probes and patch cord.

## Scanalyzer Notes

The Scanalyzer icon appears at those points in the flow chart where the Scanalyzer can be used.

**Table 4-16. Engine Temperature Sensor Specifications**

VOLTS	RESISTANCE	TEMP °C	TEMP °F
0.00	0	300	572
0.21	145	255	491
0.42	303	210	410
0.62	463	190	374
0.81	638	170	338
1.20	1042	150	302
1.59	1539	130	266
3.01	4991	85	185
4.43	25,647	40	104
4.63	41,295	25	77
4.83	93,759	10	50
4.88	134,200	0	32
4.93	232,414	-10	14

#### NOTE

*All voltage and resistance values are approximate (+/- 20%). Engine temperature sensor is measured between Terminal 9 of connector [11] and system ground (Terminals 2 and 11 of connector [10]).*





Figure 4-46. Engine Temperature Sensor Circuit

Table 4-17. Wire Harness Connectors in Figure 4-46.

NO.	DESCRIPTION	TYPE	LOCATION
[11]	ECM (gray)	12-place Deutsch	under seat
[90]	Engine temperature sensor	1-place bullet	above rear cylinder head, left side

Code 14 Test (Part 1 of 2)




\* At some point in the flow chart you may be instructed to jump directly to the box marked by an asterisk. Disregard the asterisk (but not the instruction box) if your normal progression through the chart brings you to this location.




Clear codes and confirm proper operation with no check engine lamp.

# Code 14 Test (Part 2 of 2)



**\*** At some point in the flow chart you may be instructed to jump directly to the box marked by an asterisk. Disregard the asterisk (but not the instruction box) if your normal progression through the chart brings you to this location.

 Clear codes and confirm proper operation with no check engine lamp.

## GENERAL

### Intake Air Temperature Sensor

The ECM supplies and monitors a signal at Pin 10 of [11] to one side of the intake air temperature sensor (IAT sensor). The other side of the IAT sensor is connected to a common sensor ground, which is also connected to the ECM (Pin 7 of [11]).

See [Table 4-18](#). The IAT sensor is a thermistor device, meaning that at a specific temperature, it will have a specific resistance across its terminals. As this resistance varies, so does the supplied voltage (Pin 10).

- At high temperatures, the resistance of the sensor is very low. This effectively lowers the signal voltage on Pin 10.
- At low temperatures, the resistance is very high, allowing the voltage to rise close to the supplied voltage of 5 volts.

The ECM monitors this voltage to compensate for various operating conditions.

## DIAGNOSTICS

### DiagnosticTips

The Scanalyzer displays intake air temperature in degrees.

An intermittent may be caused by a poor connection, rubbed through wire insulation or a wire broken inside the insulation.

Check for the following conditions:

- **Poor connection.** Inspect ECM harness connector for backed out terminals, improper mating, broken locks improperly formed or damaged terminals, poor terminal-to-wire connection and damaged harness.
- **Perform 4.8 WIGGLE TEST to locate intermittents.** If connections and harness check out OK, use the Scanalyzer to check intake air temperature reading while moving related connectors and wiring harness. If the failure is induced, the IAT sensor display will change.
- **Shifted sensor.** The temperature-to-resistance values table may be used to test the ET sensor at various temperature levels in order to evaluate the possibility of a shifted (out-of-calibration) sensor which may result in driveability problems.

## Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 15 flow charts.

1. Connect BREAKOUT BOX (Part No. HD-42682) to EFI harness **only** (leave ECM disconnected). See [4.7 BREA-KOUT BOX](#).
2. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), gray socket probes and patch cord.
3. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), gray pin probe and patch cord.

## Scanalyzer Notes

The Scanalyzer icon appears at those points in the flow chart where the Scanalyzer can be used.

**Table 4-18. Intake Air Temperature Sensor Specifications**

VOLTS	RESISTANCE	TEMP °C	TEMP °F
0.49	1086	125	257
0.68	1561	113	234.5
0.86	2077	100	212
1.13	2920	90	194
1.40	3889	80	176
2.25	8149	60	140
3.09	16,178	40	104
3.52	23,670	30	86
3.94	37,170	20	68
4.24	55,359	10	50
4.53	96,383	0	32
4.68	146,250	-10	14
4.83	284,118	-20	-4

**NOTE**

All voltage and resistance values are approximate (+/- 20%). Intake air temperature sensor is measured between Terminal 10 of [11] and system ground (Terminals 2 and 11 of [10]).




Figure 4-47. Intake Air Temperature Sensor Circuit

Table 4-19. Wire Harness Connectors in Figure 4-47.

NO.	DESCRIPTION	TYPE	LOCATION
[11]	ECM (gray)	12-place Deutsch	under seat
[89]	IAT sensor	2-place Deutsch	behind air cleaner backplate

# Code 15 Test (Part 1 of 2)



Connect Breakout Box to connector [11] leaving ECM disconnected. With engine at room temperature (68-86°F), use a DVOM to measure resistance across Pin 10 of [11] and Pin 7 of [11] on the Breakout Box. Is the resistance between 23,670-37,170 ohms?

YES

NO

Connect ECM to Breakout Box. Check for intermittents by performing 4.8 WIGGLE TEST. Intermittents present?



Go to Code 15 Test (Part 2 of 2).

YES

NO

While wiggling harness to locate source of intermittents, perform the steps under Code 15 Test (Part 2 of 2) marked by **Bold Asterisks**. Repair as necessary.

7715

Disconnect IAT sensor connector. Turn ignition switch ON. Using a DVOM, measure the voltage between ECM Pin 10 (+) and Pin 7 (-) of [11] on Breakout Box. Is the voltage approximately 5 volts?

YES

NO  
Less than 4.7 volts

NO  
Greater than 5.3 volts.



Replace IAT sensor (4.32 OXYGEN SENSOR), clear codes if Scana-lyzer is available and road test. Did check engine lamp come on and set only

YES

NO

Install original IAT sensor, replace ECM and road test.

System OK.

7720

7725

With IAT sensor disconnected, disconnect ECM connector [11]. Measure resistance between ECM Pin 10 of [11] and Pins 2 and 11 of [10]. Is resistance less than 1 megaohm?

YES

NO

Repair short to ground on Lt. GN/Y wire.

7730

Replace ECM. See 4.29 ELECTRONIC CONTROL MODULE.

7735

Unplug ECM leaving Breakout Box connected at vehicle harness. Measure voltage between ECM Pin 10 of [11] and Pin 2 of [10] on Breakout Box. Is the voltage 0 volts?

YES

NO

Replace ECM. See 4.29 ELECTRONIC CONTROL MODULE.

7740

Examine IAT signal wire (Lt. GN/Y) for short to 12 volts and repair.

7745




At some point in the flow chart you may be instructed to jump directly to the box marked by an asterisk. Disregard the asterisk (but not the instruction box) if your normal progression through the chart brings you to this location.



Clear codes and confirm proper operation with no check engine lamp.





\* At some point in the flow chart you may be instructed to jump directly to the box marked by an asterisk. Disregard the asterisk (but not the instruction box) if your normal progression through the chart brings you to this location.



Clear codes and confirm proper operation with no check engine lamp.

## GENERAL

### Battery Voltage

A Code 16 will set if the ECM sees battery positive voltage less than 6 volts or greater than 18 volts.

- A low voltage condition typically occurs during activation of the starter or generally indicates loose wire connections.
- A high voltage condition is usually caused by a faulty voltage regulator.

## DIAGNOSTICS

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 16 flow charts.

1. The ECM is monitoring voltage at ECM connector [10] (black) Terminal 1. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).
2. This checks for voltage drops in the ECM power circuit. If a significant voltage drop is not present, condition may be caused by excessive starter current draw.

### Scanalyzer Notes

The Scanalyzer icon appears at those points in the flow chart where the Scanalyzer can be used.




Figure 4-48. Electrical Relays




Figure 4-49. Fuse Holder





Figure 4-50. Battery Voltage Circuit

Table 4-20. Wire Harness Connectors in Figure 4-50.


NO.	DESCRIPTION	TYPE	LOCATION
[10]	ECM (black)	12-place Deutsch	under seat

Code 16 Test (Part 1 of 2)



Clear codes and confirm proper operation with no check engine lamp.

Code 16 Test (Part 2 of 2)



Clear codes and confirm proper operation with no check engine lamp.

## GENERAL


### Front Fuel Injector (Code 23) And Rear Fuel Injector (Code 32)

See [Figure 4-51](#). The fuel injectors (1, 2) are solenoids that allow pressurized fuel into the engine intake tract. The injectors are timed to the engine cycle and are triggered sequentially.

See [Figure 4-52](#). The power for the injectors comes from the ignition relay. The ignition relay also provides power for fuel pump, ECM, bank angle sensor and the ignition coils. The ECM provides the path to ground to trigger the injectors.

#### NOTE

*System fuse and ignition relay failures or wiring harness problems will cause 12 volt power to be lost to both injectors, ignition coils, ECM, bank angle sensor and fuel pump.*



1. Front Fuel Injector
2. Rear Fuel Injector
3. Clip (2)
4. Fuel Rail

Figure 4-51. Fuel Injectors

## DIAGNOSTICS

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 23/32 flow charts.

#### WARNING

The gasoline in the fuel supply line downstream of the fuel pump is under high pressure (49 psi [338 kPa]). To avoid an uncontrolled discharge or spray of gasoline, always purge the system of high pressure gas before removing fuel tank. Gasoline is extremely flammable and highly explosive. Inadequate safety precautions could result in death or serious injury.

1. Purge fuel line and remove fuel tank. See [4.37 FUEL TANK](#).
2. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), purple pin probes and patch cord.
3. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).
4. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), purple pin probes and patch cord to BREAKOUT BOX (Part No. HD-42682) and gray socket probes and patch cord to FUEL INJECTOR TEST LAMP (Part No. HD-34730-2C).




Figure 4-52. Fuel Injector Connector

### Scanalyzer Notes

The Scanalyzer icon appears at those points in the flow chart where the Scanalyzer can be used. If a number is printed next to the icon, then refer to the Scanalyzer notes at the bottom of the flow chart.





Figure 4-53. Fuel Injector Circuit

Table 4-21. Wire Harness Connectors in Figure 4-53.

NO.	DESCRIPTION	TYPE	LOCATION
[10]	ECM (black)	12-place Deutsch	under seat
[84]	Front injector	2-place	under fuel cell
[85]	Rear injector	2-place	under fuel cell

## Code 23/32 Test (Part 1 of 2)



## SCANALYZER NOTES



1


With the engine off, Scanalyzer (Active Diagnostic Test Mode) can be used to energize either the front or rear injector once each second for a total of five seconds.



2

With the engine off, Scanalyzer (Active Diagnostic Test Mode) can be used to turn fuel pump on for periods up to 30 seconds. Power to the pump also includes power to the fuel injectors and ignition coil.





Clear codes and confirm proper operation with no check engine lamp.

#### SCANALYZER NOTES



With the engine off, Scanalyzer (Active Diagnostic Test Mode) can be used to energize either the front or rear injector once each second for a total of five seconds.



With the engine off, Scanalyzer (Active Diagnostic Test Mode) can be used to turn fuel pump on for periods up to 30 seconds. Power to the pump also includes power to the fuel injectors and ignition coil.

## GENERAL

### Front Ignition Coil (Code 24) And Rear Ignition Coil (Code 25)

A Code 24 or 25 will set if the ignition coil rise time is out of range. This could occur if there is an open coil or loss of power to the coil. If both codes are set, it is likely a coil power failure or a coil failure.

See [Figure 4-54](#). The coil receives power from the ignition relay at coil pin B (4) at the same time that the fuel pump and injectors are activated. The fuel pump is active for the first two seconds after the ignition switch is turned ON and then shuts off until RPM is detected from the cam position sensors, at which time it is reactivated.

## DIAGNOSTICS

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 24/25 flow charts.

1. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), purple pin probes and patch cord.
2. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).

### Scanalyzer Notes

The Scanalyzer icon appears at those points in the flow chart where the Scanalyzer can be used. If a number is printed next to the icon, then refer to the Scanalyzer notes at the bottom of the flow chart.




Figure 4-54. Ignition Coil




Figure 4-55. Testing Ignition Coil Connectors





Figure 4-56. Ignition Coil Circuit

Table 4-22. Wire Harness Connectors in Figure 4-56.

NO.	DESCRIPTION	TYPE	LOCATION
[10]	ECM (black)	12-place Deutsch	under seat
[83]	Ignition coil connector	3-place Packard	under fuel cell, left side



## SCANALYZER NOTES



With the engine off, Scanalyzer (Active Diagnostic Test Mode) can be used to energize either the front or rear injector once each second for a total of five seconds.



With the engine off, Scanalyzer (Active Diagnostic Test Mode) can be used to turn fuel pump on for periods up to 30 seconds. Power to the pump also includes power to the fuel injectors and ignition coil.

## GENERAL

### Fuel Pump

The fuel pump assembly is shown in [Figure 4-57](#). ECM Pin 3 provides ground to the fuel pump. Code 33 will set if:

- BN/Y wire is shorted to 12 volts. This will also cause the ignition fuse to blow. See [Figure 4-58](#).
- BN/Y wire is shorted to ground. This will cause the fuel pump to run continuously even when the motor is not running.
- Fuel pump motor stalls or spins without providing fuel pressure.

## DIAGNOSTICS

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 33 flow chart.

1. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).
2. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), red pin probe and patch cord.
3. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), gray socket probe and patch cord.

### Scanalyzer Notes

The Scanalyzer icon appears at those points in the flow chart where the Scanalyzer can be used.




Figure 4-57. Fuel Pump Assembly




Figure 4-58. Ignition Fuse





Figure 4-59. Fuel Pump Circuit

Table 4-23. Wire Harness Connectors in Figure 4-59.

NO.	DESCRIPTION	TYPE	LOCATION
[10]	ECM (black)	12-place Deutsch	under seat
[39]	Instruments	10-place Multilock	under fuel cell
[86]	Fuel pump	4-place Packard	above rear cylinder head, left side



Clear codes and confirm proper operation with no check engine lamp.

## GENERAL

### Tachometer

A Code 35 will set if the PK tachometer wire is shorted to power or ground.

## DIAGNOSTICS

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 35 flow chart.

1. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See 4.7 [BREAKOUT BOX](#).

### WARNING

The gasoline in the fuel supply line downstream of the fuel pump is under high pressure (49 psi [338 kPa]). To avoid an uncontrolled discharge or spray of gasoline, always purge the system of high pressure gas before removing fuel tank. Gasoline is extremely flammable and highly explosive. Inadequate safety precautions could result in death or serious injury.

2. Purge fuel line and remove fuel tank to access instrument connector [39]. See 4.37 [FUEL TANK](#).
3. Replace tachometer. See 7.18 [TACHOMETER](#).




Figure 4-60. ECM Connectors




Figure 4-61. Speedometer/Tachometer Connector [39]







Figure 4-62. Tachometer Circuit

Table 4-24. Wire Harness Connectors in Figure 4-62.

NO.	DESCRIPTION	TYPE	LOCATION
[10]	ECM (black)	12-place Deutsch	under seat
[39]	Main harness to instruments	10-place Multilock	under fuel cell



Clear codes and confirm proper operation with no check engine lamp.

## GENERAL

### Bank Angle Sensor

See [Figure 4-63](#). A Code 44 occurs when the bank angle sensor voltage is outside the normal operating range of 0.6-1.1 volts. This may be caused by:

- Short to ground in harness between sensor and electronic control module.
- Short to voltage in harness between sensor and electronic control module.
- Failed sensor.

If this code occurs, the engine may stop running. The engine may still be restarted and ridden to the dealership for repair.

## DIAGNOSTICS

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 44 flow charts.

1. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), gray pin probes and patch cord.
2. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See [4.7 BREAKOUT BOX](#).




Figure 4-63. Bank Angle Sensor




Figure 4-64. Bank Angle Sensor Operation






Figure 4-65. Bank Angle Sensor Circuit

Table 4-25. Wire Harness Connectors in Figure 4-65.

NO.	DESCRIPTION	TYPE	LOCATION
[10]	ECM (black)	12-place Deutsch	under seat
[134]	Bank angle sensor	3-place Packard	under tail section, left side

Code 44 Test (Part 1 of 2)





Clear codes and confirm proper operation with no check engine lamp.

## GENERAL

---

### ECM Failure

All of the following codes indicate a failure which requires replacement of the ECM. See [4.29 ELECTRONIC CONTROL MODULE](#).

- Code 52 - RAM failure.
- Code 53 - ROM failure.
- Code 54 - EE PROM failure.
- Code 55 - Microprocessor failure.

*NOTE*

*Dealership technicians filing warranty claims should use job/time code **7913** for all Code 52, 53, 54 and 55 ECM replacements.*

## GENERAL

### Cam Sync Failure

This code occurs only when the engine is running if the electronic control module either does not receive a signal from the cam position sensor or receives an unexpected signal. The motorcycle may continue to run, not run normally or stop running altogether.

## DIAGNOSTICS

### Diagnostic Notes

The reference numbers below correlate with the circled numbers on the Code 56 flow charts.

1. Connect BREAKOUT BOX (Part No. HD-42682) to ECM. See 4.7 BREAKOUT BOX.
2. Use HARNESS CONNECTOR TEST KIT (Part No. HD-41404), black pin probes and patch cord.
3. See 4.30 CAM POSITION SENSOR AND ROTOR.




Figure 4-66. Cam Position Sensor







Figure 4-67. Cam Position Sensor Circuit


Table 4-26. Wire Harness Connectors in Figure 4-67.

NO.	DESCRIPTION	TYPE	LOCATION
[11]	ECM (gray)	12-place Deutsch	under seat
[14]	Cam position sensor	3-place Deutsch	near starter
[88]	TP sensor	3-place Packard	behind air cleaner backplate

Code 56 (Part 1 of 2)



Clear codes and confirm proper operation with no check engine lamp.



Clear codes and confirm proper operation with no check engine lamp.