

FUEL TANK CAPACITY	GALLONS	LITERS
Total (including reserve)	4.2	15.89
Reserve/Low Fuel Indicator at	0.4	1.51

IDLE SPEED ADJUSTMENT	
Normal Idle Speed	850-1050 RPM

TORQUE VALUES

ITEM	TORQUE		NOTES
Air Cleaner Backplate Screws	3-5 ft-lbs	4-7 Nm	page 4-113
Air Cleaner Cover Screws	27-29 in-lbs	3.1-3.3 Nm	page 4-113
Bank Angle Sensor Mounting Screw	25-27 in-lbs	2.8-3.1 Nm	page 4-98
Battery Terminal Hardware	60-96 in-lbs	7-11 Nm	page 4-105
Breather Bolts	10-15 ft-lbs	14-20 Nm	HYLOMAR, page 4-113
Canister Mounting Clamp Screws	6-8 ft-lbs	8-11 Nm	page 4-117
Coil Mounting Screws	4-6 ft-lbs	5-8 Nm	page 4-95
Engine Temperature Sensor	10-14 ft-lbs	14-19 Nm	page 4-97
Fuel Cap Flange Screws	16-18 in-lbs	1.8-2.0 Nm	special pattern to tighten, page 4-102
Fuel Filter Bracket Bolt	30-33 ft-lbs	41-45 Nm	page 4-106
Fuel Pressure Regulator Screws	15-20 in-lbs	1.7-2.3 Nm	page 4-108
Fuel Pump Mounting Nuts	68-75 in-lbs	8-9 Nm	LOCTITE THREADLOCKER 243 (blue), special tightening procedure, page 4-108
Fuel Tank Mounting Screws	9-11 ft-lbs	12-15 Nm	page 4-103
Fuel Tank Vent Valve Fitting	40-60 in-lbs	5-7 Nm	special tightening procedure, page 4-105
Ignition Rotor Mounting Bolt	43-53 in-lbs	5-6 Nm	LOCTITE THREADLOCKER 243 (blue), page 4-93
Inner Timer Cover Screws	12-20 in-lbs	1-2 Nm	page 4-93
Intake Flange Screws	6-10 ft-lbs	8-14 Nm	page 4-112
Low Fuel Level Sensor Screw	16-20 in-lbs	1.8-2.3 Nm	page 4-108
Oxygen Sensor	42-45 ft-lbs	57-61 Nm	LOCTITE ANTI-SEIZE, page 4-96
Snorkel Plate Screws	6-8 ft-lbs	8-11 Nm	LOCTITE THREADLOCKER 243 (blue), page 4-113
Timer Plate Studs	15-30 in-lbs	2-3 Nm	page 4-93

