

SUBJECT	PAGE NO.
4.1 Specifications .....	4-1
4.2 Dynamic Digital Fuel Injection .....	4-3
4.3 Diagnostic Introduction .....	4-5
4.4 Checking For Trouble Codes .....	4-6
4.5 Check Engine Lamp Diagnostics .....	4-8
4.6 Breakout Box .....	4-10
4.7 Wiggle Test .....	4-11
4.8 Initial Diagnostic Check .....	4-12
4.9 Check Engine Lamp Not Illuminated at Key ON .....	4-17
4.10 Check Engine Lamp On Continuously .....	4-20
4.11 Engine Cranks But Will Not Start .....	4-23
4.12 No ECM Power .....	4-28
4.13 Fuel Pressure Test .....	4-31
4.14 Idle Speed Control .....	4-36
4.15 Misfire .....	4-37
4.16 Trouble Code 11 .....	4-41
4.17 Trouble Code 13 .....	4-45
4.18 Trouble Code 14 .....	4-50
4.19 Trouble Code 15 .....	4-54
4.20 Trouble Code 16 .....	4-58
4.21 Trouble Codes 23 and 32 .....	4-62
4.22 Trouble Codes 24 and 25 .....	4-66
4.23 Trouble Code 33 .....	4-69
4.24 Trouble Code 35 .....	4-72
4.25 Trouble Code 36 .....	4-75
4.26 Trouble Code 44 .....	4-79
4.27 Trouble Codes 52, 53, 54 and 55 .....	4-83
4.28 Trouble Code 56 .....	4-84
4.29 Electronic Control Module .....	4-89
4.30 Cam Position Sensor and Rotor .....	4-91
4.31 Ignition Coil .....	4-95
4.32 Oxygen Sensor .....	4-97
4.33 Engine Temperature Sensor .....	4-98
4.34 Bank Angle Sensor .....	4-100
4.35 Intake Air Temperature Sensor .....	4-101
4.36 Throttle Position Sensor .....	4-102
4.37 Cooling Fan .....	4-103

4.38 Fuel Pump .....	4-104
4.39 Fuel Tank Vent Valve .....	4-110
4.40 Fuel Cap Retaining Ring .....	4-111
4.41 Throttle Body and Intake Manifold .....	4-112
4.42 Intake Leak Test .....	4-117
4.43 Airbox .....	4-119
4.44 Evaporative Emissions Control-California Models .....	4-121