

SUBJECT	PAGE NO.
4.1 Specifications	4-1
4.2 Dynamic Digital Fuel Injection	4-3
4.3 Diagnostic Introduction	4-5
4.4 Checking For Trouble Codes	4-6
4.5 Check Engine Lamp Diagnostics	4-8
4.6 Breakout Box	4-10
4.7 Wiggle Test	4-11
4.8 Initial Diagnostic Check	4-12
4.9 Check Engine Lamp Not Illuminated at Key ON	4-17
4.10 Check Engine Lamp On Continuously	4-20
4.11 Engine Cranks But Will Not Start	4-23
4.12 No ECM Power	4-28
4.13 Fuel Pressure Test	4-31
4.14 Idle Speed Control	4-36
4.15 Misfire	4-37
4.16 Trouble Code 11	4-41
4.17 Trouble Code 13	4-45
4.18 Trouble Code 14	4-50
4.19 Trouble Code 15	4-54
4.20 Trouble Code 16	4-58
4.21 Trouble Code 21	4-62
4.22 Trouble Codes 23 and 32	4-64
4.23 Trouble Codes 24 and 25	4-68
4.24 Trouble Code 33	4-71
4.25 Trouble Code 35	4-74
4.26 Trouble Code 36	4-77
4.27 Trouble Code 44	4-81
4.28 Trouble Codes 52, 53, 54 and 55	4-85
4.29 Trouble Code 56	4-86
4.30 Electronic Control Module	4-91
4.31 Cam Position Sensor and Rotor	4-93
4.32 Ignition Coil	4-97
4.33 Oxygen Sensor	4-99
4.34 Engine Temperature Sensor	4-100
4.35 Bank Angle Sensor	4-102
4.36 Intake Air Temperature Sensor	4-103
4.37 Throttle Position Sensor	4-104

4.38 Cooling Fan .....	4-105
4.39 Fuel Pump .....	4-106
4.40 Fuel Tank Vent Valve .....	4-112
4.41 Fuel Cap Retaining Ring .....	4-113
4.42 Throttle Body and Intake Manifold .....	4-114
4.43 Intake Leak Test .....	4-119
4.44 Airbox .....	4-121
4.45 Evaporative Emissions Control-California Models .....	4-123