

SUBJECT	PAGE NO.
6.1 Specifications	6-1
6.2 Primary Chain	6-3
6.3 Clutch Release Mechanism	6-7
6.4 Primary Drive/Clutch	6-9
6.5 Transmission	6-17
6.6 Transmission Case	6-18
6.7 Transmission Disassembly	6-20
6.8 Transmission Assembly	6-25
6.9 Main Drive Gear	6-29
6.10 Right Transmission Case Bearings	6-31
6.11 Left Crankcase Bearings	6-33
6.12 Transmission Installation	6-35
6.13 Shifter Pawl Adjustment	6-37
6.14 Transmission Sprocket	6-39