

SUBJECT	PAGE NO.
4.1 Specifications	4-1
4.2 Dynamic Digital Fuel Injection	4-3
4.3 Diagnostic Introduction	4-5
4.4 Checking For Trouble Codes	4-6
4.5 Check Engine Lamp Diagnostics	4-8
4.6 Breakout Box	4-10
4.7 Wiggle Test	4-11
4.8 Initial Diagnostic Check	4-12
4.9 Check Engine Lamp Not Illuminated at Key ON	4-17
4.10 Check Engine Lamp On Continuously	4-20
4.11 Engine Cranks But Will Not Start	4-23
4.12 No ECM Power	4-29
4.13 Fuel Pressure Test	4-32
4.14 Idle Speed Control	4-37
4.15 Misfire	4-38
4.16 Trouble Code 11	4-43
4.17 Trouble Code 13	4-47
4.18 Trouble Code 14	4-52
4.19 Trouble Code 15	4-56
4.20 Trouble Code 16	4-60
4.21 Trouble Code 21	4-64
4.22 Trouble Codes 23 and 32	4-67
4.23 Trouble Codes 24 and 25	4-71
4.24 Trouble Code 33	4-74
4.25 Trouble Code 35	4-77
4.26 Trouble Code 36	4-80
4.27 Trouble Code 44	4-84
4.28 Trouble Codes 52, 53, 54 and 55	4-88
4.29 Trouble Code 56	4-89
4.30 Electronic Control Module	4-93
4.31 Cam Position Sensor and Rotor	4-95
4.32 Ignition Coil	4-99
4.33 Oxygen Sensor	4-101
4.34 Engine Temperature Sensor	4-102
4.35 Bank Angle Sensor	4-103
4.36 Intake Air Temperature Sensor	4-104
4.37 Throttle Position Sensor	4-105

4.38 Cooling Fan	4-106
4.39 Fuel Pump/Early Model Year	4-107
4.40 Fuel Pump/Late Model Year	4-113
4.41 Fuel Tank Vent Valve	4-121
4.42 Fuel Cap Retaining Ring	4-122
4.43 Throttle Body and Intake Manifold	4-123
4.44 Intake Leak Test	4-128
4.45 Airbox	4-130
4.46 Evaporative Emissions Control-California Models	4-134