

SUBJECT	PAGE NO.
6.1 Specifications	6-1
6.2 Primary Chain	6-3
6.3 Clutch Release Mechanism	6-7
6.4 Primary Drive/Clutch	6-9
6.5 Transmission	6-17
6.6 Transmission Case	6-18
6.7 Transmission Disassembly	6-20
6.8 Transmission Assembly	6-25
6.9 Main Drive Gear	6-29
6.10 Right Transmission Case Bearings	6-32
6.11 Left Crankcase Bearings	6-34
6.12 Transmission Installation	6-36
6.13 Shifter Pawl Adjustment	6-38
6.14 Transmission Sprocket	6-40

1. 1.

1.

1.