

SUBJECT	PAGE NO.
7.1 Specifications	7-1
7.2 Ignition System	7-3
7.3 Diagnostic Charts	7-6
7.4 Throttle Position Sensor (TP Sensor)	7-12
7.5 Bank Angle Sensor	7-13
7.6 Ignition/Headlamp Key Switch	7-14
7.7 Auto Enrichener	7-16
7.8 Ignition Module and Cam Position Sensor	7-18
7.9 Ignition Coil	7-23
7.10 Spark Plug Cables	7-25
7.11 Starter/Ignition Interlock	7-26
7.12 Diodes	7-33
7.13 Charging System	7-34
7.14 Alternator	7-40
7.15 Voltage Regulator	7-43
7.16 Battery	7-44
7.17 Headlamp	7-49
7.18 Tail Lamp	7-51
7.19 Turn Signals	7-52
7.20 Turn Signal Flasher	7-54
7.21 Handlebar Switches	7-55
7.22 Horn	7-57
7.23 Neutral Indicator Switch	7-58
7.24 Fuses And Circuit Breakers	7-59
7.25 Electronic Speedometer	7-60
7.26 Speedometer Sensor	7-62
7.27 Speedometer Performance Check	7-63
7.28 Indicators	7-68
7.29 Main Wiring Harness	7-69

