

SUBJECT	PAGE NO.
4.1 Specifications	4-1
4.2 Dynamic Digital Fuel Injection	4-3
4.3 Diagnostic Introduction	4-5
4.4 Checking For Trouble Codes	4-6
4.5 Scanalyzer	4-8
4.6 Check Engine Lamp Diagnostics	4-11
4.7 Breakout Box	4-13
4.8 Wiggle Test	4-14
4.9 Initial Diagnostic Check	4-15
4.10 Check Engine Lamp Not Illuminated at Key ON	4-21
4.11 Check Engine Lamp On Continuously	4-24
4.12 Engine Cranks But Will Not Start	4-27
4.13 No ECM Power	4-32
4.14 Fuel Pressure Test	4-35
4.15 Idle Speed Control	4-40
4.16 Misfire	4-41
4.17 Trouble Code 11	4-45
4.18 Trouble Code 13	4-49
4.19 Trouble Code 14	4-54
4.20 Trouble Code 15	4-58
4.21 Trouble Code 16	4-62
4.22 Trouble Codes 23 and 32	4-66
4.23 Trouble Codes 24 and 25	4-70
4.24 Trouble Code 33	4-73
4.25 Trouble Code 35	4-76
4.26 Trouble Code 44	4-79
4.27 Trouble Codes 52, 53, 54 and 55	4-83
4.28 Trouble Code 56	4-84
4.29 Electronic Control Module	4-88
4.30 Cam Position Sensor and Rotor	4-90
4.31 Ignition Coil	4-94
4.32 Oxygen Sensor	4-96
4.33 Engine Temperature Sensor	4-97
4.34 Bank Angle Sensor	4-98
4.35 Intake Air Temperature Sensor	4-99
4.36 Throttle Position Sensor	4-100
4.37 Fuel Tank	4-101
4.38 Fuel Tank Vent Valve	4-104

4.39 Inline Fuel Filter	4-106
4.40 Fuel Pump	4-107
4.41 Throttle Body and Intake Manifold	4-109
4.42 Air Cleaner	4-113
4.43 Evaporative Emissions Control-California Models	4-115