

[Table Of Contents](#)

DRIVE/TRANSMISSION 6

SUBJECT	PAGE NO.
6.1 Specifications	6-1
6.2 Primary Cover	6-3
6.3 Clutch Release Mechanism	6-7
6.4 Clutch	6-9
6.5 Primary Chain	6-16
6.6 Drive Belt System	6-21
6.7 Transmission	6-25
6.8 Case Disassembly for Transmission Removal	6-26
6.9 Transmission Disassembly	6-30
6.10 Transmission Assembly	6-37
6.11 Main Drive Gear	6-39
6.12 Transmission Right Case Bearings	6-42
6.13 Transmission Left Case Bearings	6-44
6.14 Transmission Installation	6-45
6.15 Shifter Shaft	6-49
6.16 Transmission Sprocket	6-50

