

SUBJECT	PAGE NO.
1.1 General	1-1
1.2 Fluid Requirements	1-6
1.3 Body Panel Care/Maintenance	1-7
1.4 Battery	1-9
1.5 Engine Lubrication System	1-10
1.6 Brake System Maintenance	1-13
1.7 Brakes Pads and Rotors	1-15
1.8 Tires and Wheels	1-16
1.9 Clutch	1-17
1.10 Transmission/Primary Fluid	1-19
1.11 Drive Belt and Rear Sprocket	1-21
1.12 Primary Chain	1-25
1.13 Rear Shock Absorber	1-26
1.14 Front Fork Oil	1-27
1.15 Steering Head Bearings	1-29
1.16 Spark Plug	1-31
1.17 Air Cleaner	1-32
1.18 Throttle Cables	1-34
1.19 Ignition Timing and Idle Speed Adjustment	1-35
1.20 Fuel Supply Valve and Filter Strainer	1-37
1.21 Starter Interlock and Electrical Switches	1-39
1.22 Headlamp	1-40
1.23 Critical Fastener Torque Values	1-41
1.24 Storage	1-42
1.25 Troubleshooting	1-43