

[Table Of Contents](#)

DRIVE/TRANSMISSION 6

SUBJECT	PAGE NO.
6.1 Specifications	6-1
6.2 Primary Chain	6-3
6.3 Clutch Release Mechanism	6-7
6.4 Primary Drive/Clutch	6-9
6.5 Drive Belt System	6-22
6.6 Transmission	6-27
6.7 Case Disassembly For Transmission Removal	6-28
6.8 Transmission Disassembly	6-31
6.9 Transmission Assembly	6-38
6.10 Main Drive Gear	6-40
6.11 Transmission Right Case Bearings	6-43
6.12 Transmission Left Case Bearings	6-45
6.13 Transmission Installation	6-46
6.14 Shifter Shaft Installation	6-50
6.15 Transmission Sprocket	6-51

