

Figure D-1. Front and Rear Brake Systems, Right Side View

b1115xbx




Figure D-2. Rear Brake Systems, Top View

b1116xcx




Figure D-3. Rear Brake Systems, Left Side View

b1117xax





Figure D-4. Evaporative Emissions Control, California Models, Top View

b1118xbx




- 1. To induction module
- 2. From induction module (California)

- 3. From fuel tank (California)
- 4. From fuel tank to atmosphere (49 state)

Figure D-5. Evaporative Emissions Control, California and 49 State Models, Left Side View

b1119xdx




1. Intake air temperature sensor (IAT)

2. Fuel pump

Figure D-6. Wiring Harness, Left Side View

b1120xbx



- 1. Fuel injector (2)
- 2. Throttle position sensor (TPS)

- 3. Intake air temperature (IAT) sensor
- 4. Oxygen (O2) sensor

Figure D-7. Wiring Harness, Top View

b1121xcx





Figure D-8. Wiring Harness, Right Side View

b1122xax




1. Vent line
2. Feed oil line
3. Return oil line

4. Feed oil line from the oil pump to the oil cooler
5. Return oil line from the oil cooler to the oil filter housing

Figure D-9. Oil Lines, Right Side View

b1123xbx



1. Vent line

2. Feed oil line

3. Return oil line

Figure D-10. Oil Lines, Bottom View

b1124xax




Figure D-11. Clutch and Throttle Cables, Right Side View

b1125xbx




Figure D-12. Clutch, Throttle and Seat Release Cables, Left Side View

b1126xcx




Figure D-13. Clutch, Throttle and Seat Release Cables, Top View

NOTES
