


b1114xax



**Figure D-1. Front and Rear Brake Systems, Right Side View**

b1115xbx






Figure D-2. Rear Brake Systems, Top View

b1116xcx




**Figure D-3. Rear Brake Systems, Left Side View**

b1117xax



**Figure D-4. Evaporative Emissions Control, California Models, Top View**

b1118xbx




- 1. To induction module
- 2. From induction module (California)

- 3. From fuel tank (California)
- 4. From fuel tank to atmosphere (49 state)

**Figure D-5. Evaporative Emissions Control, California and 49 State Models, Left Side View**

b1119xdx




- 1. Active intake solenoid (Japan only)
- 2. Intake air temperature sensor (IAT)

- 3. Fuel pump

Figure D-6. Wiring Harness, Left Side View

b1120xbx



- 1. Fuel injector (2)
- 2. Throttle position sensor (TPS)

- 3. Intake air temperature (IAT) sensor
- 4. Oxygen (O2) sensor

**Figure D-7. Wiring Harness, Top View**

b1121xcx





Figure D-8. Wiring Harness, Right Side View



b1122xax




1. Vent line
2. Feed oil line
3. Return oil line

4. Feed oil line from the oil pump to the oil cooler
5. Return oil line from the oil cooler to the oil filter housing

**Figure D-9. Oil Lines, Right Side View**

b1123xbx




1. Vent line

2. Feed oil line

3. Return oil line

Figure D-10. Oil Lines, Bottom View

b1124xax



**Figure D-11. Clutch, Throttle Cables and Interactive Exhaust System (1200 Only), Right Side View**

b1125xbx





Figure D-12. Clutch, Throttle Seat Release Cables and Interactive Exhaust System (1200 Only), Left Side View

b1126xda



**Figure D-13. Clutch, Throttle Seat Release Cables and Active Intake System with Exhaust Valve Actuator (1200 Only), Top View**

# NOTES

---