

Table Of Contents

SUBJECT	PAGE NO.
7.1 Specifications	7-1
7.2 Ignition System	7-3
7.3 Ignition/Headlight Key Switch	7-5
7.4 Spark Plug Cables	7-9
7.5 Starter Interlock	7-11
7.6 Interactive Exhaust System (XB12 Models only)	7-18
7.7 Charging System	7-23
7.8 Alternator	7-30
7.9 Voltage Regulator	7-32
7.10 Battery Cables	7-33
7.11 Battery	7-35
7.12 Headlight	7-42
7.13 Tail Lamp	7-44
7.14 Turn Signals	7-45
7.15 Turn Signal Flasher	7-48
7.16 Handlebar Switches	7-49
7.17 Speedometer Sensor	7-51
7.18 Instrument Module	7-53
7.19 Speedometer Performance Check	7-55
7.20 Horn	7-60
7.21 Neutral Indicator Switch	7-62
7.22 Main Fuse and Fuses	7-63
7.23 Main Wire Harness	7-64
7.24 Interactive Exhaust Harness (XB12 Models)	7-69
7.25 Sprocket Cover Wiring	7-71