

Table Of Contents

SUBJECT	PAGE NO.
1.1 General	1-1
1.2 Fuel and Oil	1-5
1.3 Maintenance Schedule	1-6
1.4 Windshield Maintenance	1-9
1.5 Battery Maintenance	1-10
1.6 Engine Lubrication System	1-13
1.7 Brake System Maintenance	1-16
1.8 Tires and Wheels	1-24
1.9 Clutch	1-25
1.10 Drive Belt System	1-28
1.11 Primary Chain	1-31
1.12 Suspension Damping Adjustments	1-33
1.13 Steering Head Bearings	1-38
1.14 Spark Plugs	1-39
1.15 Air Cleaner Filter	1-41
1.16 Throttle Cable and Idle Speed Adjustment	1-43
1.17 Interactive Exhaust Cable (XB12 Models only)	1-44
1.18 Ignition Timing	1-46
1.19 Headlights	1-48
1.20 Throttle Position Sensor (TPS)	1-50
1.21 Storage	1-51
1.22 Troubleshooting	1-52

