

b1114xaxf




Figure D-1. Front and Rear Brake Systems, Right Side View

b1115abxf






Figure D-2. Rear Brake Systems, Top View

b1116acxf




**Figure D-3. Rear Brake Systems, Left Side View**

b1117aaxf



**Figure D-4. Evaporative Emissions Control, California Models, Top View**


b1118abxf



- |                                       |  |
|---------------------------------------|--|
| 1. To induction module                | 3. From fuel tank (California)             |
| 2. From induction module (California) | 4. From fuel tank to atmosphere (49 state) |

Figure D-5. Evaporative Emissions Control, California and 49 State Models, Left Side View

b1119xcxf




- 1. Active intake solenoid (Japan only)
- 2. Intake air temperature sensor (IAT)

- 3. Fuel pump

Figure D-6. Wiring Harness, Left Side View

b1120abxf



- 1. Fuel injector (2)
- 2. Throttle position sensor (TPS)

- 3. Intake air temperature (IAT) sensor
- 4. Oxygen (O2) sensor

Figure D-7. Wiring Harness, Top View

b1121acxf





Figure D-8. Wiring Harness, Right Side View



b1122xbsxf




- 1. Vent line
- 2. Feed oil line
- 3. Return oil line

- 4. Feed oil line from the oil pump to the oil cooler
- 5. Return oil line from the oil cooler to the oil filter housing

**Figure D-9. Oil Lines, Right Side View**

b1123xcxf




1. Vent line

2. Feed oil line

3. Return oil line


Figure D-10. Oil Lines, Bottom View

b1124xbxf




**Figure D-11. Clutch, Throttle Cables and Interactive Exhaust System (1200 Only), Right Side View**

b1125xcxaf



**Figure D-12. Clutch, Throttle Seat Release Cables and Interactive Exhaust System (1200 Only), Left Side View**

b1126xdxaf



**Figure D-13. Clutch, Throttle Seat Release Cables and Active Intake System with Exhaust Valve Actuator (1200 Only), Top View**

# NOTES

---